



Safety:

- Never remove the smoke or carbon monoxide detectors
- Replacing batteries is recommended twice per year to keep them fresh. A good rule of thumb is to change them when updating your clocks for daylight savings time
- Some units have a built-in lithium battery that does not need to be changed over the life of the unit
- Manufacturer recommends replacing units every 10 years

[CUSTOMER WARRANTY REQUESTS](#)

How to test detectors and change batteries:

1. Push the button on the unit once to test; the unit will chirp and/or begin speaking to you, along with the rest of the units in the house (they are hard-wired together)
2. Push and hold the button to turn the unit off; you can do this after testing or in case you accidentally set it off while cooking
3. Replacing batteries is recommend twice per year
 - a. Access the batteries by sliding the panel over
 - b. You will need a 9-volt for smoke detectors and two AA batteries for smoke/carbon monoxide detectors
4. Once batteries have been swapped, slide the panel over to secure the batteries

Maintenance and cleaning:

- Once a month, remove the unit from the mounting bracket and vacuum the alarm cover and vents with a soft brush attachment; reinstall immediately after cleaning and then test using the test/reset button
- Do not spray any detergents or solvents into the unit
- Do not paint the unit

[CUSTOMER WARRANTY REQUESTS](#)